



PRE126 Installation Guide



From Inside the vehicle

- 1) Remove current pushrod from Brake pedal and unthread from power booster.
- 2) Slide the black bracket supplied over the factory pushrod pin on your brake pedal. The "U" shaped portion of the bracket will cradle the pedal pivot boss. The new pushrod pin will point towards the driver side of the vehicle.
- 3) Re-Install Brake Light Switch onto factory pushrod pin.
- 4) Thread the new pushrod onto the power booster and attach the other end onto the new pedal pin. Adjust pedal height as needed.
- 5) Lock the pushrod into place using the supplied cotter pin.
- 6) Test your new pushrod in a safe area for proper operation and pedal height.